

Faculty of Electrical Engineering and Computer Science, VŠB-TU Ostrava

# Instructions for practical lesson

# Coverage planning of indoor wireless systems with *I-Prop* software tool

**Date:** 11.2.2014

**Author:** Ing. Libor Michalek, Ph.D. libor.michalek@vsb.cz

**Subject:** Telecommunication Networks

## Quick general instructions for coverage planning with I-Prop

#### Target practice:

- to optimally adjust the transmission parameters of WiFi access points associated with software simulation inside buildings and practically understand their meaning
- to understand the problem of propagation of radio signals inside buildings
- to learn how to work with the program I- Prop

### Before the practise, study form the lectures and recommended literature:

- the issue of transmitting radio signals in WiFi band (frequency bands, the relationship between wavelength and frequency, relationship between attenuation and gain, term Fresnel zone)
- a comparison of 802.11 standards (radio channels, transmit power, converting W to dBm, technology of spectrum DSSS, FHSS, OFDM, bit rates)


#### Assignment:,

Using the I- Prop, perform according to the instructions of the teacher:

- 1. Set the transmission parameters of the access point / WiFi access points.
- 2. Calculate and represent the coverage of selected area by WiFi signal.
- 3. Display changes in the level of the received signal with the distance of the direction of propagation .

Comment the individual settings and answer the questions to the teacher.


1. Run I-Prop (icon on the desktop).




2. Start by setting a plan of a building




3. Click on **DXF Import** button




- **4.** Choose on disk D:\student\iprop\ file **nko.dxf**.
  - **A)** Check the box *Accept* at 2nd layer.
  - B) Set the Floor Number to the value 2 and Floor Height to the value 3 m
  - C) Press Transform, then Import




**5.** Now it is necessary to calibrate the loaded floor plan. Choose the tab System Plan. Select Rescale button and draw the calibration line on the length of the room N204.




**6.** Enter the real length of the room N204: **6 meters.** 




7. Set up the model by clicking on *Project - Model Parameters* 



- **8.** Fold *Model*, choose *Multi-Wall*;
- **9.** Load the file *Default 2450 MHz.mp* saved on *D:\student\iprop*





- **10.** Location of access points:
  - A) Select the button which is marked by arrow
  - B) Click to place on the floor plan of the building and place an access point




- 11. Set parameters of the AP:
  - A) Choose Floor: 2
  - B) The height of the AP: 2m
  - **C)** Choose the type of antenna:


- isotropic ideal omni-directional
- hemispheric directional
- **D)** Enter the power level [dBm] 20 dBm max!
- E) Select the channel which is specified by the frequency by IEEE 802.11b, g Description parameter is optional.







#### 12. Click on Calculate.







- **14.** Continue with the proposal by adding next Access points. The aim is to cover all the 2nd floor of N building.
- **15.** Measurement of RSS level: Click on 3rd icon *Measurement*, drag a line in the corresponded direction of signal propagation.



**16.** The output is a graph describing the power level depending on the distance (chosen route of the line).

